4) Foggy background

Cause	Step	Check Item	Result	Action
Cleaning failure	1	Is the Cleaning Blade dirty with foreign matter, paper dust, etc. or is it scratched?	YES	Change the Cleaning Blade.
Optical failure	2	Are the mirrors and lenses dirty?	YES	Clean the mirrors and lenses.
PC Drum failure	3	Is the PC Drum dirty with foreign matter, etc.?	YES	Clean or replace the PC Drum. Change the Cleaning Blade if necessary.
	4	Is the PC Drum properly grounded?	NO	Clean or change the PC Drum Ground Plate.
Developing failure	5	Is the Sleeve Roller abnormally dirty?	YES	Clean the Sleeve Roller. Check the Developer Scattering Prevention Seal to see if it is deformed or dirty.
	6	Is the developing bias contact normal?	NO	Clean or change the developing bias contact.
Main Erase Lamp failure	7	Does the Main Erase Lamp light up properly?	NO	Replace the Main Erase Lamp.
	8	Is the Main Erase Lamp dirty?	YES	Clean the Main Erase Lamp.
AIDC Sensor failure	9	Is the AIDC Sensor clean or installed properly?	NO	Clean or reinstall the AIDC Sensor and execute F5.
	10	Is the AIDC halftone pattern dirty?	YES	Using care not to scratch, wipe the pattern with a dry soft cloth and run F5.