TABLE OF CONTENTS

1. OVERALL MACHINE INFORMATION

1. SPECIFICATIONS 1-1

2. COPY PROCESSES AROUND THE DRUM 1-4

3. COPY PROCESS CONTROL. 1-6

4. MECHANICAL COMPONENT LAYOUT 1-7

5. DRIVE LAYOUT 1-8

6. ELECTRICAL COMPONENT LAYOUT 1-10

7. ELECTRICAL COMPONENT DESCRIPTIONS 1-12

8. AC POWER AND DC POWER DISTRIBUTION 1-16

2. DETAILED SECTION DESCRIPTIONS

1. DRUM 2-1

1.1 OPC DRUM CHARACTERISTICS 2-1

1.2 DRUM UNIT 2-2

2. DRUM CHARGE 2-3

2.1 OVERVIEW. 2-3

2.2 CHARGE CORONA WIRE CLEANER MECHANISM 2-4

2.3 CHARGE CORONA CIRCUIT 2-5

2.4 GRID VOLTAGE CORRECTION 2-6

2.4.1 Drum Residual Voltage Correction (Vr correction) 2-6

2.4.2 Vp Correction 2-7

2.5 GRID VOLTAGE CONTROL 2-8

2.5.1 Image Density Control. 2-8

2.5.2 Toner Density Detection 2-8

2.5.3 Vr Detection 2-8

3. OPTICS 2-9

3.1 OVERVIEW. 2-9

3.2 SCANNER DRIVE 2-10
3.2.1 1st and 2nd Scanner Drive Mechanism 2-10
3.3 LENS DRIVE. 2-11
3.3.1 Lens Drive 2-11
3.3.2 Shading Mechanism 2-11
3.3.3 Lens Positioning 2-12
3.4 4TH AND 5TH MIRROR DRIVE 2-13
3.4.1 Drive 2-13
3.4.2 Positioning. 2-13
3.5 ORIGINAL SIZE DETECTION IN PLATEN MODE (A111 Copier Only). 2-14
3.6 AUTOMATIC IMAGE DENSITY SENSING 2-16
3.7 EXPOSURE LAMP VOLTAGE CORRECTION 2-17
3.7.1 VL Correction. 2-17
3.7.2 Drum Wear Correction 2-17
3.7.3 Reproduction Ratio Correction 2-17
3.8 EXPOSURE LAMP VOLTAGE CONTROL 2-18
3.8.1 Base Lamp Voltage Factor in Manual Image Density Mode 2-19
3.8.2 Base Lamp Voltage Factor in Auto Image Density Mode 2-19
3.8.3 VL Correction Factor 2-20
3.8.4 Drum Wear Correction Factor 2-21
3.8.5 Reproduction Ratio Correction Factor. 2-21
3.9 EXPOSURE LAMP CONTROL CIRCUIT 2-22
4. ERASE 2-23
4.1 OVERVIEW. 2-23
4.1.1 Lead Edge Erase 2-24
4.1.2 Side Erase. 2-24
4.1.3 Trail Edge Erase 2-25
4.1.4 Editing Mode Erase. 2-25
5. DEVELOPMENT 2-27
5.1 OVERVIEW. 2-27
5.2 DRIVE MECHANISM 2-28
5.3 CROSS-MIXING 2-29

5.4 DEVELOPMENT BIAS FOR IMAGE DENSITY CONTROL 2-30
5.4.1 Base Bias Voltage Factor in Manual Image Density Control 2-30
5.4.2 Base Bias Voltage Factor in Automatic Image Density Control 2-31
5.4.3 Base Bias Voltage Adjustment Factor 2-32
5.4.4 Vr Correction Factor 2-33
5.5 DEVELOPMENT BIAS CIRCUIT 2-34
5.6 COLOR DEVELOPMENT UNIT DETECTION 2-35
6. TONER DENSITY DETECTION AND TONER SUPPLY 2-36
6.1 DETECT SUPPLY MODE 2-36
6.2 ID SENSOR FUNCTION IN DETECT SUPPLY MODE 2-37
6.3 FIXED SUPPLY MODE 2-38
6.4 ID SENSOR FUNCTION IN FIXED SUPPLY MODE 2-39
6.4.1 Black Development Unit 2-39
6.4.2 Color Development Unit 2-39
6.5 ABNORMAL CONDITION IN TONER DENSITY DETECTION 2-40
6.6 DEVELOPMENT BIAS TONER DENSITY DETECTION 2-40
6.6.1 Toner Density Adjustment Factor 2-40
6.6.2 Vd Correction Factor (Only for Black Toner) 2-41
6.7 TONER SUPPLY AND AGITATOR DRIVE MECHANISM 2-42
6.8 TONER SUPPLY AMOUNT 2-43
6.8.1 Detect Supply Mode (SP30 = 0) 2-43
6.8.2 Fixed Supply Mode (SP30 = 1) 2-45
6.9 BLACK TONER END DETECTION 2-47
6.9.1 Near Toner End Condition 2-47
6.9.2 Toner End Condition 2-47
6.9.3 Toner End Recovery 2-48
6.10 COLOR TONER END DETECTION 2-49
6.11 COLOR TONER SUPPLY UNIT INITIAL SETTING (SP63) 2-50
7. IMAGE TRANSFER AND PAPER SEPARATION 2-51
7.1 PRE-TRANSFER LAMP (PTL) 2-51
7.2 IMAGE TRANSFER 2-51
7.3 PAPER SEPARATION 2-52

7.4 PRE-TRANSFER LAMP AND TRANSFER/SEPARATION CORONA CIRCUIT 2-53

8. DRUM CLEANING 2-54

8.1 OVERVIEW. 2-54

8.2 DRIVE MECHANISM 2-55

8.3 TONER OVERFLOW DETECTION 2-56

9. QUENCHING. 2-57

10. PAPER FEED AND REGISTRATION 2-58

10.1 OVERVIEW. 2-58

10.2 FRR FEED SYSTEM 2-59

10.2.1 Pick-up Roller 2-59

10.2.2 Feed and Reverse Rollers 2-59

10.3 1ST FEED STATION PAPER LIFT MECHANISM AND PAPER END DETECTION 2-61

10.3.1 Paper Lift Mechanism 2-61

10.3.2 Paper End Detection 2-62

10.4 2ND/3RD FEED STATION PAPER LIFT MECHANISM AND PAPER END DETECTION 2-63

10.4.1 Paper Lift Mechanism 2-63

10.4.2 Paper End Detection 2-63

10.5 PAPER SIZE DETECTION 2-64

10.5.1 1st Feed Station 2-64

10.5.2 2nd/3rd Feed Station. 2-66

10.6 PAPER FEED DRIVE MECHANISM 2-68

10.6.1 1st Feed Station 2-68

10.6.2 2nd Feed Station 2-69

10.6.3 3rd Feed Station (A111 Copier Only) 2-70

10.7 SLIP CLUTCH MECHANISM 2-71

10.8 MANUAL FEED TABLE 2-72

10.9 PAPER REGISTRATION 2-73

10.10 PAPER FEED AND MISFEED DETECTION TIMING 2-74

11. IMAGE FUSING 2-76

11.1 OVERVIEW. 2-76

11.2 FUSING DRIVE RELEASE MECHANISM AND COVER SAFETY SWITCH . . 2-77
11.3 FUSING LAMP CONTROL 2-78
11.4 ENERGY SAVER FUNCTION 2-79
11.5 FUSING LAMP CONTROL CIRCUIT 2-80
11.5.1 Phase Control Mode 2-81
11.5.2 Overheat Protection 2-82

3. INSTALLATION

1. INSTALLATION REQUIREMENTS 3-1
1.1 ENVIRONMENT 3-1
1.2 MACHINE LEVEL 3-1
1.3 MINIMUM SPACE REQUIREMENTS 3-2
1.4 POWER REQUIREMENTS 3-2
2. INSTALLATION PROCEDURE 3-3
2.1 ACCESSORY CHECK 3-3
2.2 COPIER INSTALLATION 3-4
2.3 CASSETTE MODIFICATION 3-10
2.4 KEY COUNTER HOLDER INSTALLATION (Option) 3-11
2.5 OPTICS ANTI-CONDENSATION HEATER INSTALLATION (Option) 3-12
2.6 COLOR DEVELOPMENT UNIT INSTALLATION (Option) 3-13
2.7 DC POWER SUPPLY UNIT INSTALLATION (A110 Copier Only) (Option) 3-15

4. SERVICE TABLES

1. SERVICE REMARKS 4-1
1.1 GENERAL CAUTION 4-1
1.2 DRUM AND DRUM UNIT 4-1
1.3 CHARGE CORONA 4-2
1.4 OPTICS 4-2
1.5 DEVELOPMENT UNIT 4-3
1.6 TONER SUPPLY 4-4

1.7 TRANSFER AND SEPARATION 4-4
1.8 CLEANING UNIT 4-4
1.9 FUSING UNIT 4-5
1.10 PAPER FEED 4-5
1.11 DOCUMENT FEEDER 4-5
1.12 SORTER 4-6
1.13 OTHERS 4-6
2. SERVICE PROGRAM MODE 4-7
2.1 SERVICE PROGRAM MODE OPERATION 4-7
2.1.1 Service Program Access Procedure 4-7
2.1.2 Change Adjustment Values or Modes 4-9
2.1.3 Memory Clear Procedure 4-9
2.2 SERVICE PROGRAM MODE TABLE 4-12
2.3 SP-8 SENSOR/SWITCH DATA CHECK 4-24
2.4 SP-9 ELECTRICAL COMPONENT CHECK 4-26
2.5 MISFEED LOCATION INDICATOR 4-28
2.5.1 Initial Misfeed Detection 4-28
2.5.2 Misfeed Detection During Copy Cycle 4-29
3. SERVICE TABLES 4-30
3.1 TEST POINTS 4-30
3.2 DIP SWITCHES 4-31
3.3 VARIABLE RESISTORS 4-33
4. SPECIAL TOOLS AND LUBRICANTS 4-34
5. PREVENTIVE MAINTENANCE SCHEDULE 4-35
5.1 PM TABLE 4-35
5.2 EXPLANATION OF REGULAR PM 4-39
5.3 REGULAR PM PROCEDURE 4-41

5. REPLACEMENT AND ADJUSTMENT

1. EXTERIOR AND INNER COVERS 5-1

1.1 EXTERIOR COVER REMOVAL 5-1
1.1.1 Front Cover 5-1
1.1.2 Right Cover 5-1
1.1.3 Left Lower Cover 5-2
1.1.4 Left Upper Cover 5-2
1.1.5 Rear Cover 5-3
1.1.6 Upper Cover 5-3
1.2 INNER COVER REMOVAL 5-4
1.2.1 Right Inner Cover 5-4
1.2.2 Left Inner Cover 5-4
2. OPTICS 5-5
2.1 EXPOSURE GLASS REMOVAL 5-5
2.2 1ST MIRROR REMOVAL 5-6
2.3 2ND AND 3RD MIRROR REMOVAL 5-8
2.4 4TH AND 5TH MIRROR REPLACEMENT 5-10
2.5 EXPOSURE LAMP REPLACEMENT 5-11
2.6 OPTICS THERMOSWITCH REPLACEMENT 5-13
2.7 SCANNER DRIVE WIRE REPLACEMENT 5-14
2.7.1 Wire Removal 5-14
2.7.2 Wire Installation 5-15
2.8 SCANNER MOTOR REPLACEMENT 5-21
2.9 LENS MOTOR REPLACEMENT 5-22
2.10 LENS DRIVE WIRE INSTALLATION 5-23
2.11 4TH/5TH MIRROR MOTOR REPLACEMENT 5-24
3. DEVELOPMENT AND TONER SUPPLY 5-25
3.1 TONER SUPPLY UNIT REMOVAL 5-25
3.2 DEVELOPER REPLACEMENT 5-26
3.3 INLET SEAL REMOVAL 5-27
3.4 TONER SUPPLY CLUTCH REPLACEMENT 5-28
3.5 DEVELOPMENT CLUTCH SOLENOID REPLACEMENT 5-29
3.6 DEVELOPMENT DRIVE CLUTCH REPLACEMENT 5-30
3.7 DEVELOPMENT BIAS VOLTAGE ADJUSTMENT (SP9-57) 5-32

4. CLEANING 5-33

4.1 CLEANING UNIT REMOVAL 5-33

4.2 CLEANING BLADE REPLACEMENT. 5-34

4.3 CLEANING BRUSH REPLACEMENT 5-35

4.4 BLADE SCRAPER REPLACEMENT 5-36

4.5 TONER OVERFLOW SENSOR REPLACEMENT 5-37

4.6 USED TONER COLLECTION 5-38

4.7 ENTRANCE SEAL REPLACEMENT 5-39

5. PAPER FEED 5-40

5.1 1ST PAPER SIZE SWITCH REPLACEMENT 5-40

5.2 1ST PAPER END SENSOR AND PAPER LIFT SENSOR REPLACEMENT. . . 5-41

5.3 1ST FEED ROLLER, PICK-UP ROLLER, AND REVERSE ROLLER REPLACEMENT. 5-42

5.4 2ND AND 3RD PAPER FEED ROLLER REPLACEMENT. 5-44

5.5 RELAY SENSOR REPLACEMENT (A111 Copier Only) 5-45

5.6 PICK-UP ROLLER RELEASE SOLENOID AND MANUAL FEED TABLE SWITCH REPLACEMENT 5-46

5.7 1ST PAPER FEED CLUTCH SOLENOID REPLACEMENT 5-47

5.8 PAPER LIFT CLUTCH SOLENOID ASSEMBLY REPLACEMENT 5-48

5.9 REGISTRATION CLUTCH REPLACEMENT 5-50

5.10 2ND PAPER FEED CLUTCH AND RELAY ROLLER CLUTCH REPLACEMENT. 5-51

5.11 3RD PAPER FEED CLUTCH REPLACEMENT (A111 Copier Only) 5-53

5.12 2ND AND 3RD PAPER END SENSOR REPLACEMENT 5-54

5.13 2ND AND 3RD PAPER SIZE SWITCH REPLACEMENT 5-55

5.14 REGISTRATION SENSOR AND ROLLER REPLACEMENT. 5-56

6. AROUND DRUM. 5-59

6.1 DRUM REPLACEMENT. 5-59

6.2 ID SENSOR REPLACEMENT 5-61

6.3 PICK-OFF PAWL REPLACEMENT 5-62

6.4 PTL BOARD REPLACEMENT 5-63

6.5 QUENCHING LAMP REPLACEMENT/CLEANING 5-64

6.6 ERASE LAMP REPLACEMENT. 5-65

6.7 CHARGE CORONA WIRE REPLACEMENT 5-66
6.8 CHARGE CORONA GRID REPLACEMENT 5-67
6.9 TRANSFER/SEPARATION CORONA WIRE REPLACEMENT 5-68
6.10 CORONA CURRENT ADJUSTMENT 5-69
6.10.1 CHARGE CORONA CURRENT ADJUSTMENT (SP9-2) 5-71
6.10.2 GRID VOLTAGE ADJUSTMENT (SP9-2) 5-73
6.10.3 TRANSFER CORONA CURRENT ADJUSTMENT (SP9-5) 5-74
6.10.4 SEPARATION CORONA CURRENT ADJUSTMENT (SP9-8) 5-75
7. FUSING 5-76
7.1 EXIT UNIT REMOVAL 5-76
7.2 FUSING LAMP REPLACEMENT 5-77
7.3 PRESSURE ROLLER REPLACEMENT 5-78
7.4 HOT ROLLER REPLACEMENT 5-80
7.5 THERMISTOR AND THERMOFUSE REPLACEMENT 5-82
7.6 FUSING PRESSURE ADJUSTMENT 5-83
7.7 FUSING EXIT SENSOR REPLACEMENT 5-84
8. OTHERS 5-85
8.1 OPERATION PANEL REMOVAL 5-85
8.2 OZONE FILTER REPLACEMENT 5-86
9. COPY QUALITY ADJUSTMENT 5-87
9.1 LIGHT INTENSITY ADJUSTMENT 5-88
9.2 UNEVEN EXPOSURE ADJUSTMENT 5-89
9.3 BIAS VOLTAGE ADJUSTMENT 5-90
9.4 TONER DENSITY ADJUSTMENT 5-91
9.5 FIXED TONER SUPPLY MODE SELECTION 5-91
9.6 TONER SUPPLY RATIO SELECTION 5-91
9.7 ID SENSOR (Vsg) ADJUSTMENT 5-92
9.8 ADS (Auto Image Density Sensor) ADJUSTMENT 5-93
9.9 VERTICAL MAGNIFICATION ADJUSTMENT 5-94
9.10 HORIZONTAL MAGNIFICATION ADJUSTMENT 5-94
9.11 FOCUS ADJUSTMENT 5-95
9.12 ERASE MARGIN ADJUSTMENT 5-96

9.13 REGISTRATION ADJUSTMENT 5-96
9.14 SIDE-TO-SIDE REGISTRATION ADJUSTMENT 5-97
9.15 4TH/5TH MIRROR HEIGHT ADJUSTMENT 5-100

6. TROUBLESHOOTING

1. COPY QUALITY 6-1
1.1 BLANK COPY (WHITE COPY). 6-1
1.2 DIRTY BACKGROUND 6-4
1.3 UNEVEN IMAGE DENSITY 6-7
1.4 VERTICAL BLACK BANDS 6-8
1.5 VERTICAL BLACK LINES 6-9
1.6 VERTICAL WHITE LINES OR BANDS–1 (DULL OR BLURRED) 6-10
1.7 VERTICAL WHITE LINES OR BANDS–2 (THIN, DISTINCT) 6-11
1.8 HORIZONTAL BLACK/WHITE LINES 6-12
1.9 JITTER 6-13
1.10 BLACK SPOTS ON THE COPY IMAGE 6-14
1.11 SKEWED (OPTICAL) COPY IMAGE 6-15
1.12 TONER DENSITY TOO HIGH 6-16
1.13 TONER DENSITY TOO LOW. 6-18
1.14 TONER SCATTERING 6-20
1.15 UNFUSED COPY IMAGE. 6-21
1.16 PAPER MISFEED. 6-22
1.17 DF ORIGINAL MISFEED OR SKEW 6-23
2. U-CODE CONDITION 6-24
2.1 U1 - RIGHT COVER OPEN 6-24
2.2 U2 - KEY COUNTER NOT SET 6-24
2.3 U4 - SORTER OPEN 6-24
2.4 U5 - CASSETTE LIFT SENSOR NOT ON 6-24
2.5 U7 - DUPLEX UNIT OPEN DURING DUPLEX OPERATION 6-24
3. SERVICE CALL CONDITION. 6-25
3.1 CODE #11 – EXPOSURE LAMP ERROR 6-25

3.2 CODE #12 – EXPOSURE LAMP ERROR 6-27
3.3 CODE #13 – ZERO CROSS SIGNAL ERROR 6-28
3.4 CODE #21 – SCANNER HOME POSITION ERROR 6-29
3.5 CODE #22 – SCANNER HOME POSITION ERROR 6-31
3.6 CODE #28 – LENS HOME POSITION ERROR 6-33
3.7 CODE #29 – LENS HOME POSITION ERROR 6-35
3.8 CODE #2A – 4TH/5TH MIRROR HOME POSITION ERROR 6-37
3.9 CODE #2B – 4TH/5TH MIRROR HOME POSITION ERROR 6-39
3.10 CODE #52 – FUSING WARM-UP ERROR 6-41
3.11 CODE #53 – FUSING OVERHEAT 6-43
3.12 CODE #55 – FUSING THERMISTOR OPEN 6-44
3.13 E70 (IN THE MAGNIFICATION INDICATOR) – TONER OVERFLOW SENSOR ON 6-46
3.14 CODE #80 – DUPLEX AND COPIER MAIN BOARD COMMUNICATION ERROR 6-47
3.15 CODE #82 – JOGGER HOME POSITION ERROR 6-50
3.16 CODE #83 – JOGGER HOME POSITION ERROR 6-51
3.17 ABNORMAL CONDITION IN TONER DENSITY DETECTION 6-52

4. ELECTRICAL COMPONENT DEFECTS 6-54

4.1 SENSOR 6-54
4.2 SWITCH OR OTHER ELECTRICAL COMPONENT 6-56
4.3 BLOWN FUSE CONDITION 6-57
4.3.1 A110 copier 6-57
4.3.2 A111 Copier 6-58

DOCUMENT FEEDER

1. SPECIFICATIONS 1

2. COMPONENT LAYOUT 2

3. ELECTRICAL COMPONENT DESCRIPTIONS 3

4. OVERALL MACHINE CONTROL 4

5. BASIC OPERATION 6

6. POWER DISTRIBUTION 8

6.1 A110 COPIER 8

6.2 A111 COPIER 9

7. ORIGINAL FEED 10

7.1 ORIGINAL PICK-UP 10

7.2 ORIGINAL SEPARATION 11

7.3 ORIGINAL FEED-IN MECHANISM 12

7.4 ORIGINAL SIZE DETECTION 14

7.5 ORIGINAL INVERSION MECHANISM 15

7.6 ORIGINAL FEED-OUT MECHANISM 17

7.7 BELT DRIVE MOTOR CIRCUIT 18

7.8 FEED-OUT MOTOR CIRCUIT 19

7.9 INPUT AND OUTPUT CIRCUITS 20

8. LIFT MECHANISM 21

9. ORIGINAL MISFEED SENSING 22

10. INSTALLATION PROCEDURE (for Machine Code: A110/A111) . . 24

10.1 ACCESSORY CHECK 24

10.2 INSTALLATION PROCEDURE 27

11. PREPARATION FOR TRANSPORTATION 34

12. REPLACEMENT AND ADJUSTMENT 35

12.1 FEED-IN UNIT 35

12.1.1 Transport Belt Replacement 35

12.1.2 Feed-in Unit Removal 37

12.1.3 Pick-up Roller Replacement 38

12.1.4 Feed-in Clutch Lubrication 39

12.1.5 Pick-up Solenoid Adjustment 40

12.1.6 Feed Roller Replacement 42

12.1.7 Feed-in Solenoid Adjustment 43

12.1.8 Friction Belt Replacement 44

12.2 FEED-OUT UNIT 45

12.2.1 Feed-out Unit Removal 45

12.2.2 Inverter Solenoid Adjustment 46
12.2.3 DF Leading Edge Registration Adjustment 47
12.3 BELT DRIVE MOTOR SPEED ADJUSTMENT 48

SORTER

1. SPECIFICATIONS 1
2. COMPONENT LAYOUT 2
3. ELECTRICAL COMPONENT DESCRIPTIONS 3
4. OVERALL MACHINE CONTROL 4
5. BASIC OPERATION 5
6. EXIT ROLLER DRIVE 6
6.1 ROLLER DRIVE MECHANISM 6
6.2 ROLLER DRIVE CIRCUIT 7
7. BIN DRIVE 8
7.1 BIN DRIVE MECHANISM 8
7.2 BIN DRIVE CIRCUIT 10
8. MISFEED DETECTION 11
9. INSTALLATION PROCEDURE (for Machine Code: A110/A111) . . . 12
9.1 ACCESSORY CHECK 12
9.2 INSTALLATION PROCEDURE 13
10. PREPARATION FOR TRANSPORTATION 16
11. ROLLER DRIVE BELT REPLACEMENT 17
12. BIN GUIDE LUBRICATION 18

DUPLEX

1. SPECIFICATIONS 1
2. COMPONENT LAYOUT 2
3. ELECTRICAL COMPONENT DESCRIPTION 3

4. POWER DISTRIBUTION AND OVERALL MACHINE CONTROL 4

4.1 A110 COPIER 4

4.2 A111 COPIER 5

5. BASIC OPERATION 6

5.1 FIRST SIDE COPY 6

5.2 DUPLEX STACKING 6

5.3 SECOND SIDE COPY 6

6. DRIVE MECHANISM 7

7. FIRST SIDE COPY 8

7.1 FROM COPIER PAPER FEED SECTION TO DUPLEX ENTRANCE ROLLER . . 8

7.2 FROM DUPLEX ENTRANCE ROLLER TO DUPLEX TRAY 9

7.3 DUPLEX STACKING 10

8. SECOND SIDE COPY 11

9. DUPLEX PAPER FEED AND MISFEED DETECTION TIMING 12

10. INSTALLATION PROCEDURE 13

10.1 ACCESSORY CHECK 13

10.2 INSTALLATION PROCEDURE 14

11. REPLACEMENT AND ADJUSTMENT 19

11.1 DUPLEX TRAY REMOVAL 19

11.2 JOGGER MOTOR AND JOGGER HOME POSITION SENSOR REPLACEMENT 21

11.3 TURN SENSOR REPLACEMENT 22

11.4 FEED MOTOR REPLACEMENT 23

11.5 PAPER END SENSOR REPLACEMENT 24

11.6 ENTRANCE SENSOR REPLACEMENT 25

11.7 GATE SOLENOID REPLACEMENT 26

11.8 FRICTION ROLLER REPLACEMENT 27

11.9 FEED ROLLER REPLACEMENT 28