1.2 Self-Diagnostic Mode

Keys pressed simultaneously	Mode	Description	Clearing	Indication
0+1	All control-panel LEDs ON mode	All LEDs on the control panel come on.	"Clear/Stop" key	—
0+2	Aging mode	Aging	"09"	AG
0+3	Test mode	Motor test and input/output check (including initialization)	"09"	CH
0+4	Test mode	Motor test and input/output check	"09"	CH
0+5	Adjustment mode	Various adjustments	"09"	AJ
0+6	Forced ready mode	Forces the copier to become ready.	"09"	AG
0+7	Aging mode	Aging (with ADF)	"09"	AG
0+8	Setting mode	System changing and setting defaults and PM counter	"09"	AD

Note: How to access each mode:

While pressing the two keys for the mode to access (ex. "0" and "5" for the adjustment mode), turn on the main (power) switch.

<Procedure>

- All control-panel LEDs ON mode (01) :

[0][1] / [Power] → [All control-panel LEDs come on] → [C/S] → Clear

- Aging mode (02) :

[0][2] / [Power] → [Aging operation] → [C/S] → [0][9] → Clear

[PRINT]

- Test mode (03 or 04) :

For this mode, refer to the "Input/Output Check" on page 1-6.

- Adjustment mode (05) :

For this mode, refer to the "Adjustment Mode" on page 1-9.