1-2-1 Drum

Note the following when handling or storing the drum.

- While the cleaning unit and the developing unit are detached from the copier or the drum is being replaced, make sure that the drum surface is protected from strong, direct light.
- Keep the drum at an ambient temperature between –20°C/–4°F and 40°C/104°F and humidity not higher than 85% RH. Avoid abrupt changes in temperature and humidity even within the allowable ranges.
- Avoid exposing the drum to gases which are harmful to or may affect the quality of the drum.
- Handle the drum with care. Avoid impacts. Never touch the drum surface. If it is stained, clean it.
- If the copier is left open for more than 5 minutes for maintenance, remove the drum and store it in the storage bag (part No.78369020).

1-2-2 Developer and toner

Store the developer and toner in a cool, dark place. Avoid direct light, high humidity and temperature.

1-2-3 Dehumidifier

The dehumidifier prevents condensation inside the copier. As long as the power plug is connected, power is supplied to the dehumidifier even when the main switch is turned off and the heater switch is turned on.
When the transfer charger heater and cassette heater (optional) is installed, as long as the power plug is connected, power is supplied to the cassette heater even when the main switch is turned off.
Turn on the heater switch and do not unplug the power cord when the humidity is 70% RH or higher.
If the copier will not be used for a long time, unplug the power cord.

1-2-4 Copy paper

Store copy paper away from direct sunlight or high humidity. If the copier will not be used for a long time, take out the paper from the cassette and wrap it in the original wrapping paper.