8-2. Original Size Detecting Sensors Locations

- The original size detecting sensors are located in the following positions to enable them to detect different sizes of the original.

Areas \ Sensors	CD1 (PC114)	CD2 (PC116)	FD2 (PC113)	FD3 (PC115)
Metric Areas	❍	●	❍	●
Inch Areas	❍	●	❍	●
Mixed inch/metric Areas	❍	❍	❍	❍

❍: Standard ●: Optional



