10-5. ATDC Sensor

The ATDC Sensor detects the toner-to-carrier ratio (T/C) of the developer in the Developer Mixing Chamber.



1177M023AB

	CONTROL SIGNAL	T/C	Reference Voltage	WIRING DIAGRAM
UN3	PWB-A PJ10A-6	5%	2.5V	1-D