2-2. REMOVAL OF PWBs

- When removing a PWB, first go over "PRECAUTIONS FOR HANDLING THE PWBs" contained and use the removal procedures given on the next page.
- Replacement of a PWB may call for readjustments or resetting of particular items.
- The removal procedures given on the next page omit the steps to unplug connectors and remove the PWB from the PWB support.

