(3) Removal of the Imaging Unit





Fig. 1 Removal of the Fixing Screws



NOTE

When the Imaging Unit is installed, the positioning pins should fit in the indentations in the flange of the PC Drum. (The fixing screws should also be tightened firmly.)
If the positioning pins are not properly aligned with the indentations in the PC Drum flange, turn the end of the PC Drum until they fit into position.

