

(6) Removal of the Fusing Unit



Removal of the Fusing Unit Locking Plate



Parts to be Taken Apart in the Rear

