

Fig. 1 Fig. 2 1177D076AA

Step 1. Decrease the adjustment value in Adjust Mode A9 until void occurs on the copy image. (Fig. 1)

↓

Step 2. Increase the adjustment value in Adjust Mode A9 until the void on the copy image disappears (the edge of the Shading Sheet) to find the exact value at which the void disappears.

NOTE

Increase the A9 adjustment value only gradually.

↓

Step 3. Input a value that is the value found in step 2 plus 25 (which is equivalent to about 3 mm). (Fig. 2)

↓

Example: If the void disappears at 85 (adjustment value)
85 + 25 = 110 (Input 110 as the adjustment value.)

↓

Step 4. Make a copy and check that the Scanner does not hit against the right side bracket.

↓

Step 5. This completes the shading position correction procedure.