### (7) Trouble Code Counters

- This function shows the number of malfunctions that have occurred at different locations in the copier.

<Setting Procedure>

- Each press of the Paper Select key changes the contents of the display in the following order.

***NOTE***

*The malfunction counters are displayed only when their counts are "1" or more. If the count of all counters is "0," then the message "All 0" appears.*

| Order | Malfunction Code | Description | Order | Malfunction Code | Description |
|---|---|---|---|---|---|
| 1 | C0000 | An Upper Drive Motor malfunction | 12 | C0950 | A 4th Drawer malfunction |
| 2 | C0010 | A Lower Drive Motor malfunction | 13 | C0990 | A Paper Feed Cabinet Main Tray malfunction |
| 3 | C004A | An Optical Section Cooling Fan Motor malfunction | 14 | C0998 | A Paper Feed Cabinet Shift Tray malfunction |
| 4 | C004C | A Ventilation Fan Motor malfunction | 15 | C099E | A Shift Gate position error |
| 5 | C004E | A Power Supply Unit Cooling Fan Motor malfunction | 16 | C0F02 | An Original Size Detecting Unit malfunction |
| 6 | C0070 | A Toner Replenishing Motor malfunction | 17 | C0F30 | An ATDC Sensor malfunction |
| 7 | C0500 | Warming-up failure | 18 | C0F79 | A Paper Empty Sensor malfunction |
| 8 | C0510 | An abnormally low fusing temperature | 19 | C0FE1 | An Original Size Detecting Sensor malfunction |
| 9 | C0520 | An abnormally high fusing temperature | 20 | E2 | An ATDC automatic adjustment failure |
| 10 | C0600 | A Scanner Motor malfunction | 21 | Ar1 | Copier watchdog |
| 11 | C0900 | A 3rd Drawer malfunction | 22 | Ar2 | ADF watchdog |

<Clearing a Count>

1. Show the count of the counter to be cleared.
2. Press the Clear key to clear the count. If a count is mistakenly cleared, press the Stop key to undo the clearing command.