(8) Consumables Counters

- This function shows the number of copy processes to which different parts or supplies have been subjected.

<Setting Procedure>

- Each press of the Paper Select key changes the contents of the display in the following order.

Order	Description	Order	Description
1	IU	4	BLADE
2	DRAM	5	FUSING
3	DEVELOPER		

<Clearing a Count>

1. Show the count of the counter to be cleared.
2. Press the Clear key to clear the count. If a count is mistakenly cleared, press the Stop key to undo the clearing command.

NOTE

The copier gives the M2 display when the count of IU, Developer, Blade, or Fusing reaches the setting. It also gives the M4 display when the Drum count reaches 80K.

(9) Input Paper Size

- This function allows the Tech. Rep. to enter the size of the paper loaded in each drawer.

<Setting Procedure>

1. Each press of the Paper Select key changes the contents of the display in the following order.

Order	Description	Order	Description
1	2nd DRAWER (FD)	4	3rd DRAWER (CD)
2	2nd DRAWER (CD)	5	4th DRAWER (FD)
3	3rd DRAWER (FD)	6	4th DRAWER (CD)

2. Show the paper size to be set and press the Clear key to clear the current size.
3. From the Keypad, enter the new paper size.

(10) Display Test

- This function, when invoked, causes all LEDs on the control panel to blink and the Message Display to alternate between black and white to determine if the control panel is fully operational.

<Setting Procedure>

1. Press the Start key to start the check sequence.
2. Press the Panel Reset key to go back to the Tech. Rep. Mode menu screen.