PF-207 Paper Take-Up Misfeed Clearing Procedure

- Paper is not taken up at all.

Step	Check	Result	Action
1	Paper meets product specifications.	NO	Change paper.
2	Paper is curled, wavy, and damp.	YES	Change paper. Instruct user in correct paper storage.
3	Paper Take-Up/Separator Rolls are deformed, worn, and have paper dust	YES	Clean or change.
4	Paper Take-Up Motor turns when the Start key is pressed	NO	Correct the drive coupling. Change motor, PF-207 Master Board, and/or Master Board.

- Paper is at a stop at the Vertical Transport Rollers.

Step	Check	Result	Action
1	Vertical Transport Rollers are deformed, worn, and have paper dust	YES	Clean or change.
2	Paper take-up guide plate and vertical transport guide plate are dirty and deformed.	YES	Clean, correct, or change.
3	Vertical Transport Motor turns when the Start key is pressed	NO	Correct the drive coupling. Change motor, PF-207 Master Board, and/or Master Board.
4	3rd Drawer Paper Take-Up Sensor operation: the voltage across PJ8A-2A on the PF-207 Master Board and GND is DC5V (sensor unblocked) and DC0V (sensor blocked).	YES	Change PF-207 Master Board and Master Board.
		NO	Correct actuator. Change sensor.
5	4th Drawer Paper Take-Up Sensor operation: the voltage across PJ4A-2 on the PF-207 Master Board and GND is DC5V (sensor unblocked) and DC0V (sensor blocked).	YES	Change PF-207 Master Board and Master Board.
		NO	Correct actuator. Change sensor.
6	Vertical Transport Sensor 4 operation: the voltage across PJ8A-12A on the PF-207 Master Board and GND is DC5V (sensor unblocked) and DC0V (sensor blocked).	YES	Change PF-207 Master Board and Master Board.
		NO	Correct actuator. Change sensor.