
3 ADJUSTMENT

3-1. JIGS AND TOOLS USED


◆Important

- When adjusting the copier, use the jigs shown below:
- The position of the Scanner and Mirrors Carriage: jigs no. ③ and ④
- The gap between the Doctor Blade and Sleeve Roller: jigs no. ⑤ and ⑥
- The position of the PC Drum Paper Separator Fingers: jigs no. ⑤ and ⑦
- Jig no. ②, Pre-Drive Inhibit Switch Actuating Jig, is the same as the Interlock Switch Jig used for model EP3170.
- Jig no. ⑥, D.B. Adjusting jig, is the same as the one used for model EP1080.


① Front Door Interlock Switch Actuating Jig




② Pre-Drive Inhibit Switch Actuating Jig




③ Scanner Positioning Jig




④ Scanner/Carriage Positioning Jig



⑤ Sleeve/Magnet Roller Positioning Jig



⑥ D.B. Adjusting Jig



⑦ PC Drum Paper Separator Finger Positioning Jig

