

Adjustment procedure

When the copy of dimension A is 17 mm or less: decrease the setting.
When the copy of dimension A is 23 mm or more: increase the setting.

10. Press the Panel Reset key to return to the initial mode.