13-4-2. Positioning and Locking of the Paper Drawer

The drawer is positioned when its ribs fit into the slots in the rail located on the paper take-up end of the copier. See the illustration below. The drawer is locked into position when the magnet mounted in the Magnet Mounting Bracket is attracted by the metal plate fitted to the copier frame. The drawer reference position is adjusted by moving the Magnet Mounting Bracket to the front or rear. For details, see "DIS/REASSEMBLY, ADJUSTMENT."



