


| Screen Display | | Description |
|---|---|---|
| Toner Collecting | Count | 1 count per 1 copy |
| | Setting | Set the number of copy cycles from after toner disposal to the next maintenance time. |

* The maximum setting is 6 digits.
* When the count exceeds the setting, the following screen is shown on the Message Display to indicate that an inspection time has come.




| Screen Display | | Description |
|---|---|---|
| Copy Kit | Count | 1 count per 1 copy |
| | Setting | Set the number of copy cycles from after copy kit replacement to the next maintenance time. |

* The maximum setting is 6 digits.
* The count of the copy kit is not made unless "Mode 1" or "Mode 2" has been selected in the Copy Kit Counter Mode.
* When the count exceeds the setting, the following screen is shown on the Message Display to indicate that an inspection time has come.




Screen display resetting method

To reset the screen display, clear the count after inspection (disposal or replacement).