Code No.	Key Name
1	Multi-Copy Key "1"
2	Multi-Copy Key "2"
3	Multi-Copy Key "3"
4	Multi-Copy Key "4"
5	Multi-Copy Key "5"
6	Multi-Copy Key "6"
7	Multi-Copy Key "7"
8	Multi-Copy Key "8"
9	Multi-Copy Key "9"
10	Multi-Copy Key "0"
11	Clear Key
12	Energy Saver Key
13	Interrupt Key
14	Panel Reset Key
15	Access Mode Key
16	Start Key
17	Paper Select Key
18	Auto Paper Mode Key
19	Zoom Up Key
20	Zoom Down Key

Code No.	Key Name
21	Exposure Control Key (Lighter)
22	Exposure Control Key (Darker)
23	Auto Exposure Mode Key
24	Enlargement Key
25	Full Size Key
26	Reduction Key
35	OK Key
36	Cursor Key
61	DT Setting (Drum Dehumidify Key)
62	Counter Clear (Book Mode Key)
63	Port (File Margin Mode Key)
64	Memory (Erase Mode Key)
65	Initial Transmission (Auxiliary Toner Replenishing Key)
66	Data Load (Insertion Mode Key)
67	Level History (Cover Mode Key)
68	Card-2→Card-1 (Meter Count Key)
69	Tech. Rep. ID Code (Manual Staple Key)
70	Mixed Original Detection Mode Key
71	Original Count Mode Key
72	Memory Input Key