
4 ADJUST MODE


Adjust mode setting procedure

1) Open the System Panel.
2) Press the Stop Key.
3) Press Multi-Copy Key "0".
4) Press the Stop Key.
5) Press Multi-Copy Key "1".
6) The following screen appears on the Message Display:




1136S143CA

7) Press Multi-Copy Key "1".
8) Press the Stop Key.
9) Press the Start Key.
10) The following screen appears on the Message Display.




1136S175CA

11) By pressing the OK Key, the screen changes as shown below:




1136S175CA

OK Key




1136S176CA

OK Key




1136S177CA

OK Key




1136S178CA

OK Key



1136S179CA

OK Key



1136S180CA

OK Key