Types of User's Choice Modes

Mode	Description
Language Select	Used to select the language shown on the Message Display.
Mixed Orig. Detect	Used to set whether originals of assorted sizes can be used or not when the Automatic Document Feeder is used.
Original Thickness	Used to set whether lightweight originals can be used or not when the Automatic Document Feeder is used.
Copy Mode Priority	Used to set the priority mode selected automatically (Auto Paper Select/Auto Magnification Select/Manual) when the Power Switch is turned ON or the Panel Reset Key is pressed.
Paper Priority	Used to set the paper port selected automatically for the Auto Paper Select or Manual Mode.
Exposure Priority	Used to set the priority exposure mode (Manual/Auto) selected when the Power Switch is turned ON or the Panel Reset Key is pressed. *The exposure level can also be set for manual exposure.
Finishing Priority	Used to set the priority finishing mode (Non Sort/Sort/Group/Staple) when the Power Switch is turned ON with the copier equipped with the Sorter.
Auto Exp. Level	Used to set the priority exposure level in the Auto Exposure mode when the copier has been set so that the Auto Exposure mode is selected in the initial mode.
Manual Expo. Adjust	Used to set the priority exposure level in the Manual Exposure mode when the copier has been set so that the Manual Exposure mode is selected in the initial mode.
Counter Removal	Used to set whether the Control Panel is to be reset or not when the Plug-In Counter is removed.
Intelligent Sort	Used to set whether switching to Sort or Non-Sort is automatically made according to the number of originals/copy cycles when the copier is equipped with a Sorter and Duplexing/Automatic Document Feeder.
Energy Saver Mode	Used to set whether or not the copier is automatically placed in the Energy Saving Mode a given length of time after a copy cycle has ended. *When YES has been selected, the time may be entered.
Auto Panel Reset	Used to set whether or not the Control Panel is automatically initialized a given length of time after a copy cycle has ended. *When YES has been selected, the time may be entered.
Drum Dehumidify	Used to set whether or not the copier is automatically placed in the Drum Dehumidify Mode after the copier has completed warming up.
Special Paper	Used to designate special types of paper loaded in each Drawer for the Automatic Paper Size Mode and automatic paper source switching function.
Custom 2-in-1	Used to store in memory various settings that are automatically called up when the 2-in-1 mode is selected.
Custom Book Mode	Used to store in memory various settings that are automatically called up when the Book mode is selected.
Custom 2-in-1 Separation	Used to store in memory various settings that are automatically called up when the 2-in-1 Separation mode is selected.
Administrator Mode	Used to enter the User Help Code, send the Code to the center, set whether Copy Track is performed or not, set the maximum limit to the number of copy cycles set with the Multi-Copy Keys, register/change the Access No., and clear the Account Counter.