

Counter Removal



1136S110CA


Intelligent Sort



1136S115CA

Condition	Screen Display	Operation
The copy cycle is initiated using a single original in the Sort Mode.	YES	The copier switches from Sort to Non-Sort.
	NO	The copier remains in the Sort Mode.
The copy cycle is initiated to make two or more copies using two or more originals in the Non-Sort Mode.	YES	The copier switches from Non-Sort to Sort.
	NO	The copier remains in the Non-Sort Mode.


Energy Saver Mode



1136S109CA

* When "YES" has been selected, enter the time required to start the Energy Saver Mode using the Multi-Copy Keys (1 to 10 minutes).


Auto Panel Reset



1136S108CA

* When "YES" has been selected, enter the time required to start the automatic panel reset function using the Multi-Copy Keys (1, 2, 3 or 5 minutes).

Drum Dehumidify



1136S130CA