
When "Copy Track" has been selected

Procedure


1) Using the Cursor Key, select "YES" or "NO".
2) Press the OK Key to move to the setting of the next option.



1136S138CA

"YES" selected

"NO" selected



1136S139CA


"Max. Copy Sets" indicates the maximum number of copy cycles that can be entered using the Multi-Copy Keys.

Procedure

1) Using the Cursor Key, select "YES".
2) Press the Clear Key to clear the number of copy cycles and use the Multi-Copy Keys to input the maximum number of copy cycles.
3) Press the OK Key to enter the value and switch to either of the following screens:



1136S136CA



1136S118CA

"Copy Track Data" is used to register and change the identification number and clear the count on an account basis and is shown when "Copy Track" YES has been selected.

Procedure

1) Using the Cursor Key, select "Copy Track Data".
2) By pressing the OK Key, the screen changes as shown below:



1136S140CA

3) Using the Cursor Key, select the desired item. By pressing the OK Key, the screen changes as shown below: