
6) Show the data for P11 and check that the data for the 1st port has changed from "H" to "L."




1136T041AA

PC56 is operational if the data is "L." PC56 is faulty if the data is "H."