	Code	Description	Sensor Layout
Original Size Detecting Board	C0FF0	Original Size Detecting Sensor ❺ failure	(Metric Areas) • ❶: PC116, ❷: PC117, ❸: PC118 (option), ❹: PC115, ❺: PC119 (option) • A to E: Sensor locations  (Inch Areas) • ❶: PC116 (option), ❷: PC117, ❸: PC118 (option), ❹: PC115 
	C0FF1	Original Size Detecting Sensors ❶ and ❺ failure	
	C0FF2	Original Size Detecting Sensors ❷ and ❺ failure	
	C0FF3	Original Size Detecting Sensors ❶, ❷, and ❺ failure	
	C0FF4	Original Size Detecting Sensors ❸ and ❺ failure	
	C0FF5	Original Size Detecting Sensors ❶, ❸, and ❺ failure	
	C0FF6	Original Size Detecting Sensors ❷, ❸, and ❺ failure	
	C0FF7	Original Size Detecting Sensors ❶, ❷, ❸, and ❺ failure	
	C0FF8	Original Size Detecting Sensors ❹ and ❺ failure	
	C0FF9	Original Size Detecting Sensors ❶, ❹, and ❺ failure	
	C0FFA	Original Size Detecting Sensors ❷, ❹, and ❺ failure	
	C0FFB	Original Size Detecting Sensors ❶, ❷, ❹, and ❺ failure	
	C0FFC	Original Size Detecting Sensors ❸, ❹, and ❺ failure	
	C0FFD	Original Size Detecting Sensors ❶, ❸, ❹, and ❺ failure	
	C0FFE	Original Size Detecting Sensors ❷, ❸, ❹, and ❺ failure	
	C0FFF	Original Size Detecting Sensors ❶, ❷, ❸, ❹, and ❺ failure (Metric Areas)	