* C0520, C0522

Step	Check Item	Result	Action
1	Does H1 remain lit up even after the copier has completed warming up?	YES	Perform step 2.
		NO	Perform steps 3 and 4. *
2	Check to see if H1 is turned OFF by changing the H1 ON/OFF signal from PWB-A. (See p. T-3, 4.) 1) Port: P1-7 2) Select the function "Port."		
	3) Is the data for P1-7 set to "1"? Port Data P0 1H11L*** P1 H1010111↓ 1136T109CA	NO	Replace PWB-A.
	4) Does H1 go out when the data for P1-7 is changed from "0" to "1"?	NO	Replace SSR.
3	Disconnect CN47 (4P). Is the circuit across CN47-2 and 3 on the Fusing Unit side short-circuited?	YES	Replace TH1
		NO	Replace PWB-A.
	Disconnect CN48 (4P). Is the circuit across CN48-2 and 3 on the Fusing Unit side short-circuited?	YES	Replace TH2.
		NO	Replace PWB-A.