* C099A, C099b

Step	Check Item	Result	Action
1	Is C099b being shown?	YES	Perform step 3.
2	Block PC3 and check PC3 as follows. (See p. T-5, 6.) 1) Port: P39-8 2) Select the function "Port."		
	3) Is the data for P39-8 set to "L"?  1136T123AA	NO	Check PWB-H and flat cable and replace PC3.
		YES	First replace PF-102 PWB-A, then replace EP2050 PWB-A if necessary.
3	Unblock PC3 and check PC2 as follows. (See p. T-5, 6.) 1) Port: P39-8 2) Select the function "Port."		
	3) Is the data for P39-8 set to "H"?  1136T124AA	NO	Check PWB-H and flat cable and replace PC3.
		YES	First replace PF-102 PWB-A, then replace EP2050 PWB-A if necessary.

* C099C

Step	Check Item	Result	Action
1	Does M27 turn when the Drawer is slid in with a paper stack loaded in the Shift Tray?	YES	Perform step 3.
2	Does the voltage across PJ11A-3 (moving to right) on PF-102 PWB-A and GND change from DC0V to DC24V when the Drawer is slid in with a paper stack loaded in the Shift Tray? (M27)	NO	First replace PF-102 PWB-A, then replace EP2050 PWB-A if necessary.
		YES	Replace M27 or check PWB-H and flat cable.
3	Does the voltage across PJ10-12 on PF-102 PWB-A and GND change in the range between DC0V and DC5V while M27 is turning? (PC6)	NO	Check the pulse disk and PWB-H. Replace PC6.
		YES	First replace PF-102 PWB-A, then replace EP2050 PWB-A if necessary. Check gears and for overload.