Step	Check Item	Result	Action
3	Let a sheet of paper push up the actuator of PC20 and, in that condition, check PC20 as follows. (See p. T-5, 6.) 1) Port: P35-8 2) Select the function "Port."		
	3) Is the data for P35-8 set to "L"? ▶P35 **HHHH*L P36 HH00HL** P37 **00LL00↓ 1136T132AA	NO	Check the actuator. Check PC20.
	4) Slide out the 3rd Drawer and make sure that no paper is loaded on the Tray.		
	5) Select "Port" again. Port Data ▶P0 1H11L*** P1 H1010111↓ 1136T133CA		
	6) Show the data for P35-8. Has the data changed from "L" to "H"?	NO	Check the actuator. Replace PC20.
	▶P35 **HHHH*H P36 LH00HL** P37 **00HH00↓ 1136T134AA	YES	First replace PF-102 PWB-A, then replace EP2050 PWB-A if necessary.