

11. Pull the harness out to the front from the rear frame.

12. Remove five screws and the Paper Take-Up Unit.

