

(7) Cleaning of Fusing Thermoswitch TS1




1. Remove the Temperature Detector Assy.
2. Using a soft cloth dampened with alcohol, wipe clean the thermoswitch.

(8) Replacement and Cleaning of the Cleaning Roller




1. Remove two screws and the Upper Cover.
2. Remove the Cleaning Roller.
3. Replace the Cleaning Roller with a new one.




4. Using a brush, whisk dust off the Cleaning Roller.

(9) Replacement and Cleaning of the Upper Fusing Roller



1. Remove the Upper Fusing Roller.
2. Replace the Upper Fusing Roller with a new one.



3. Using a soft cloth dampened with alcohol or silicone oil, wipe clean the Upper Fusing Roller.