
FUSING/PAPER EXIT SECTION
Fusing Thermistor1
TH1
(SM) CN47
(GR/P1) CN4
TS1
Fusing Thermoswitch
Fusing Heater Lamp
H1
(L) CN5
Fusing Thermistor2
TH2
(SM) CN48
Exit/Duplex Switching Solenoid
SL5
(EM) CN79
(CT) CN74
Paper Exit Switch
S53
(EM) CN57
Fusing Section Cooling Fan Motor
M15
OPTICAL
UN2
Original Size Detecting Board
PC119
PC118
PC115
PC117
PC116
Original Size Detecting Sensor CD2
Original Size Detecting Sensor FD3
Original Size Detecting Sensor CD1
Original Size Detecting Sensor FD2
Original Size Detecting Sensor FD1 (*1)
(*1)
Inch Areas: Option
Metric Areas: Standard
DEVELOPING SECTION
HV1
High Voltage Unit
(CT) PJ26
Developing Bias
Sub Hopper Toner Replenishing Motor
M9
Main Hopper Toner Replenishing Motor
M8
Separator Solenoid
SL1
PWB-G
AIDC Sensor Board
UN3
ATDC Sensor
(PH) PJ49
Toner Bottle Home Position Sensor
PC35
Toner Empty Detecting Switch
S106
LA2
Main Erase Lamp
LA3
Image Erase Lamp
Paper Transport Clutch
CL1
Synchronizing Roller Clutch
CL2
(SM) CN62
M3
(CT) PJ17A
(CT) PJ14A
(CT) PJ12A
(CT) PJ34A
(CT) PJ18A
(CT) PJ19A
(CT) PJ20A
(CT) PJ15A
(CT) PJ16A
(CT) PJ27A
(CT) PJ21A
Not Use
PJ32A
Main Drive Motor
M1
(UP-4) PJ27
(CT) CN16
(YL) CN15
EP5000
EP4000