
ECTION
PWB-H
AE Sensor Board
(CT) PJ1H
Exposure Thermal Fuse
TF1
Exposure Lamp
LA1
Size Reset Switch
S108
(SM) CN24
(SM) CN7
GND
(CT) CN31
Lens Motor
M6
Mirror Motor
M7
(CT) PJ47
(CT) PJ4F
(CT) PJ4B
PJ3F
Scanner Motor
M2
PWB-F
SCP Board
(UP-4) PJ1F
(CT) PJ2B
PWB-B
MSC Board
Not Use
PJ3B
(UP-4) PJ1B
(CT) PJ4B
(CT) PJ30
UN1
Control Panel
(YL) CN45
(YL) CN46
Mirror Reference Position Sensor
PC86
(CT) PJ32
Lens Reference Position Sensor
PC90
(CT) PJ31
Scanner Reference Position Sensor
PC81
(CT) PJ43
(CT) PJ6F
(CT) PJ5F
(CT) PJ2F
Total Counter
CNT1
(SM) CN21
Toner Collecting Box Set Sensor
PC107
(CT) PJ12
Pre-Drive OFF Switch
PC27
(CT) PJ13
Original Cover Detecting Sensor
PC111
(CT) PJ24
Suction Fan Motor
M4
(SM) CN83
Original Cooling Fan Motor
M5
(SM) CN84
Right Upper Door SW
S22
(CT) PJ41
Left Upper Door SW
S23
(CT) PJ42
(CT) PJ11A
(CT) PJ9A
(CT) PJ7A
(CT) PJ33A
(CT) PJ6A
(CT) PJ3A
(CT) PJ8A
(CT) PJ2A
PJ10A
PJ13A
(CT) PJ25
PWB-I
Tech.Rep.Settings Switches Board
PWB-R
RAM Board
PJ31A
PJ30A
(CT) PJ4A
(CT) PJ5A
(CT) PJ2BA
(CT) PJ22A
(CT) PJ25A
(CT) PJ23A
(CT) PJ24A
(CT) PJ26A
(CT) PJ29A
120V AREAS
PJ23A
(SM) CN56
Plug-In Counter (Option)
CNT2
Not Use