◆CONNECTOR LAYOUT





Description

Number of Pin → ①···Possible to confirm by removing external cover.

→ [1]···Not possible to confirm by removing external cover.