
1
2
3
4
A
B
C
D
E
F
G
H
I
A (0-19)
D (0-7)
DC5V1
IC1
IC2
IC3
IC4
IC6
IC7
IC8
IC10
Not Use PJ3 5
Not Use PJ3 7
Not Use PJ3 8
Not Use PJ3 9
Not Use PJ3 10
Not Use PJ3 11
Not Use PJ3 4
Not Use PJ3 25
DT-CS (IC7)
READY (IC4)
Power Sig PJ2 1
GND1
MINET (DC5V) PJ2 8
MINET (TXD) PJ2 7
MINET (ADF5V) PJ2 4
MINET (ADFTXD) PJ2 3
MINET_RXD (D-102) PJ2 2
MINET (SCP5V) PJ2 6
MINET (SCPTXD) PJ2 5
MINET (5V) PJ2 10
MINETTXD PJ2 9
DT RXD PJ3 3
DT-CS (IC1)
DT TXD PJ3 2
CSROM (IC4)
CSRAM (IC4)
CRD (IC4)
(IC2)
(IC4)
RESET
RESET (IC4)
PJ3 23 RESET
PJ1
DC5V0
GND0