

10 IMAGE ERASE LAMP

To prevent a black band from occurring across both the leading and trailing edges, and along the front and rear edges, of the electrostatic latent image, 40 LEDs of Image Erase Lamp LA3 are turned ON before development takes place, thereby reducing to a minimum the unnecessary potential on the surface of the PC Drum.



1156M010AA

The position of LA3 can be adjusted using the adjusting screw at the front of the copier.



1156M011AA