Flat Spring	Connection
A	Between varistor-and-resistor and guide plate ⑦
B	Between varistor-and-resistor and guide plate ②
C	Between guide plates ② and ④
D	Between guide plates ② and ①
E	Between guide plates ④ and ⑥