PM Parts List

● PAPER TAKE-UP SECTION

● OPTICAL SECTION

K=1,000 copies

PM Parts	Maintenance Cycle (K)		Parts No.	QTY	Disassembly Page
	Clean	Replace			
Paper Take-Up Roll	60	180	4425-3009-01	2	D-16
Feed Roll *1	60	180	1052-5224-01	2	D-16
Separator Roll *1	60	180	4479-0152-01	2	D-16
Upper Synchronizing Roller	60				D-20
Lower Synchronizing Roller	60				D-20
Paper Dust Remover	60	180	1074-3316-01	1	D-21
Upper Pre-Image Transfer Guide Plate	60				D-52
Multi Bypass Table					
Paper Take-Up Roll	60	180	1139-3316-01	1	D-27
Feed Roll *1		180	1052-5224-01	1	D-27
Separator Roll *1		180	1136-0162-01	1	D-27
Mirrors and Lens	60				D-30
Cooling Fan Filter	180				D-37
Scanner Rail *2	180				D-28
Scanner Shaft *2	180				D-28
6th Mirror Protective Filter	60				D-37

*1: Replace the Feed Roll and Separator Roll as a set.
*2: Wipe these parts with a dry cloth, then lubricate them.

● IMAGING UNIT

PM Parts	Maintenance Cycle (K)		Parts No.	QTY	Disassembly Page
	Clean	Replace			
Starter		180		1	D-45
Front Ds Positioning Collar	60				D-42
Rear Ds Positioning Collar	60				D-42
Toner Antispill Trap	60				D-42
Developer Scattering Prevention Plate	60	180	1134-5119-19	1	D-42