PREFACE 前書き

1. The part numbers listed in Parts Manual are those which were assigned to the parts making up the machine at the time machine was originally introduced onto the market.

2. Parts whose numbers are preceded by an asterisk in the Index Column on the List Page are parts to be used in only certain market areas. Therefore, please check the number in the Area cloumn on the List Page and then compare it with the numbers given in the Area Chart on page II to find out which part number is applicable to your own ares.
   NOTE: Parts for only certain Market Areas: The part numbers for these parts vary according to market area. In orther cases, these parts are used in only restricted areas.

3. The Index Number on the List Page is composed of two numbers and two letters. Generally, only A is used as the first letter of the two letters. However, sometimes B, C, D, ets. are used when one part in the illustration, such as an electrical parts or a part which varies according to market ares, has two or more part numbers. The second of the two letters represents themodification history of that part.

4. The Ares Number is listed in the Ares Column for only those parts used in certain market areas. This Area Number represents the ares listed opposite to It in the Chrat given on Page II. Parts having no Area Number listed in the Area Column can be used in all market areas.

5. In the exploded views in this parts manual parts (Screws & Washes, etc...) which are indicated with a "four-digit" numbers are listed in numerical order in the section "SCREWS AND WASHERS". Please check these "four-digit"numbers with the part numbers ("ten-digit" number) which should be used for ordering the part.

6. All parts numbers consist of "ten-digit" wtich should all be quoted when ordering a part. The price of parts can be obtained by referring to the "Parts Price List" which is separately issued.

7. All infomation contained in this parts manual is subject to change.

1．パーツマニュアルには、販売当初の機械を構成している部品が記載されています。

2．リスト部の表示番号(INDEX)に※印がある部品は仕向部品ですので、地域No.(AREA No.)をIIページの地域No.対比表で照合して、国内の部品番号(PART No.)を使用してください。
注）仕向部品……地域により部品番号が異なる、または、一部地域にだけ使用されている部品。

3．リスト部の表示番号は、部品図の番号をあらわす2桁の数字と2桁の補助記号より構成されています。
補助記号の1桁目は、一般にはAだけですが、仕向部品、電気部品のように1つの部品図で複数の部品番号をあらわしている場合にA．B．C．…となっています。補助記号の2桁目は部品の変更経歴をあらわしています。

4．リスト部の地域No.は仕向部品にだけ記載されており、IIページでその部品の使用されている地域をあらわしています。地域No.のないものは全地域使用部品です。

5．ネジ・ワッシャー類は、数字4桁の表示番号を使用しています。ネジ・ワッシャー部で照合の上、10桁の部品番号を使用してください。

6．部品番号は10桁で構成されています。注文は必ず10桁の部品番号を使用してください。

7．このパーツマニュアルの内容は予告なく変更されることがあります。