<Clearing Procedures>

- Initialize Points PJ2
  1. Turn OFF the Power Switch.
  2. With PJ2 closed, turn ON the Power Switch.
  3. In approx. 5 sec. open PJ2.
  4. Check that the message "Initialize completed" is shown on the Touch Panel, then touch "Enter."
- Memory Clear Test Point TP3
  1. Turn OFF the Power Switch.
  2. With the circuit across TP1 and 3 closed, turn ON the Power Switch.
  3. In approx. 5 sec. open the circuit across TP1 and 3.
  4. Check that the message "Memory Clear completed" is shown on the Touch Panel, then touch "Enter."

NOTE

- If an erratic operation or display occurs, perform the clearing procedures in the order of PJ2 and TP3.
- When memory clear has been performed, make the necessary settings again.

<List of Data Cleared by Switches and Points>

Clearing Method / Data Cleared	Front Door Open/Close	Trouble Reset Switch (S1)	Initialize Switch (PJ2)	Memory Clear Test Point (TP3)
Misfeed display	○	○	○	○
Malfunction display (except Exposure Lamp and fusing system)	○	○	○	○
Malfunction display (all including Exposure Lamp and fusing system)	–	○	○	○
Erratic operation/display	–	–	○	○
User mode	–	–	–	○
Service mode	–	–	–	○
F5/F7 setting values	–	–	–	○
System Input	–	–	–	○
Accessory Test	–	–	–	○
Level History	–	–	–	○
Adjust mode	–	–	–	○

○ : Cleared (initialized) – : Not cleared: