Touch Panel Display	Setting (The default is **Highlighted** .)
Orig. ▶ Copy Default	Select the type of Orig. ▶ Copy setting selected automatically when the copier is turned ON or Panel Reset key pressed. If "Duplex only" is selected for "Simplex/Duplex" of the "Tech. Rep. Choice" function, neither 1 ▶ 2 nor 1 ▶ 2in1 are displayed. 1 ▶ 1 | 1 ▶ 2 in1 **1 ▶ 2** | 1 ▶ 2-2 in1 | 2 ▶ 2 NOTE: Some of the functions may not be displayed depending on the type of options the copier is equipped with.
Auto Power-OFF Mode	Select whether to turn ON or OFF the Auto Shut Off function that shuts down the copier a given period of time after a copy cycle has been completed or the last key operated. Selecting "ON" means setting the time it takes the Auto Shut Off function to be activated, that can range from 1 min. to 120 min. OFF | 1 to 120 **(60 min.)** NOTE: "OFF" is displayed when "Enable" is selected for "Non-Auto Shut off" of the "Tech. Rep. Choice" function.
Original on Glass	Select whether to turn "ON" or "OFF" the beep that sounds when you attempt to load an original in the document feeder with another one left on the glass. **Beep ON** | Beep OFF
Administrator Mode	The entry of the "Administrator #" set using the Tech. Rep. mode permits the settings of the following functions.
Copy Track	Select the number of accounts to be controlled. **OFF** | 100 Accounts | 1000 Accounts
Copy Track	This function is displayed when the above "Copy Track" setting is changed, prompting you to select whether to initialize ("YES") the copy track data so far taken or not ("NO") YES (initialize) | NO (do not initialize)
Copy Track Data	When "Count Reset" is touched, it clears all data under control.