<table>
<tr><th>Touch Panel Display</th><th>Operation</th></tr>
<tr><td>Image Exposure</td><td>Vary the Vg voltage to set the desired image density.
<table>
<tr><th>Display</th><th>Description</th><th>Display</th><th>Description</th></tr>
<tr><td>47</td><td>Vg –90V</td><td>51</td><td>Vg +30V</td></tr>
<tr><td>48</td><td>Vg –60V</td><td>52</td><td>Vg +60V</td></tr>
<tr><td>49</td><td>Vg –30V</td><td>53</td><td>Vg +90V</td></tr>
<tr><td>50</td><td>Vg ± 0V</td><td>54</td><td>Vg +120V</td></tr>
</table></td></tr>
<tr><td>Simplex/Duplex</td><td>Select the copying mode types that can be selected in “Orig. ▶ Copy Default” of User’s Choice.
<table>
<tr><td>Both</td><td>Permits selection of all copying modes.</td></tr>
<tr><td>Duplex only</td><td>Permits selection of 2-sided copying modes only.</td></tr>
</table></td></tr>
<tr><td>Non-Auto Shut off</td><td>Select whether to enable or disable the Auto Power–OFF Mode setting available from User’s Choice.
<table>
<tr><td>Disable</td><td>“OFF” key is not displayed.</td></tr>
<tr><td>Enable</td><td>“OFF” key is displayed.</td></tr>
</table></td></tr>
<tr><td>Universal Tray 13”x</td><td>Set the inch size of paper to be used in the Universal Tray.
<table>
<tr><td>8½”</td><td>8¼”</td><td>8”</td></tr>
</table></td></tr>
<tr><td>Universal Tray 14”x</td><td>Set the inch size of paper to be used in the Universal Tray.
<table>
<tr><td>8½”</td><td>8¼”</td></tr>
</table></td></tr>
<tr><td>Automatic feeding adjust</td><td>Select whether to display the number of originals that need to be returned when a jam occurs while using the ADF.
<table>
<tr><td>YES</td><td>NO</td></tr>
</table></td></tr>
</table>