<table>
<tr><th>Touch Panel Display</th><th>Operation</th></tr>
<tr><td>Jam</td><td>
Shows the number of misfeeds that have occurred in different parts of the copier system including MCBJ (system, copier only, ADF).

<Jam Counter 1/3>
<table>
<tr><th>Display</th><th>Description</th><th>Display</th><th>Description</th></tr>
<tr><td>MCBJ (System)</td><td>Misfeed occurrence rate of the entire system</td><td>1st Drawer</td><td>No. of misfeeds that occurred at the 1st Drawer of the copier</td></tr>
<tr><td>MCBJ (Machine Only)</td><td>Misfeed occurrence rate of the copier only</td><td>2nd Drawer</td><td>No. of misfeeds that occured at the 2nd Drawer of the copier</td></tr>
<tr><td>MCBJ (ADF)</td><td>Misfeed occurrence rate of the ADF only</td><td>3rd Drawer</td><td>No. of misfeeds that occurred at the 3rd Drawer of the copier</td></tr>
<tr><td>Manual Feed</td><td>No. of misfeeds that occurred at the Multi Bypass Tray</td><td>4th Drawer</td><td>No. of misfeeds that occurred at the 4th Drawer of the copier</td></tr>
</table>
Note 1: MCBJ (System) : Total Counter value divided by the sum of Jam Counter values
MCBJ (Machine Only) : Total Counter value divided by the sum of copier Jam Counter values
MCBJ (ADF) : No. of originals fed through the ADF divided by the sum of ADF Jams.
Note 2: A minus sign "–" is appended when the denominator is "0" for each MCBJ.

<Jam Counter 2/3>
<table>
<tr><th>Display</th><th>Description</th><th>Display</th><th>Description</th></tr>
<tr><td>5th Drawer</td><td>No. of misfeeds that occurred at the 5th Drawer of the copier</td><td>Dup Entrance</td><td>No. of misfeeds that occurred at the entrance of the Duplex Unit</td></tr>
<tr><td>Vertical Trans.</td><td>No. of misfeeds that occurred at the transport section of the copier</td><td>Dup Exit</td><td>No. of misfeeds that occurred at the paper take-up section of the Duplex Unit</td></tr>
<tr><td>Horizontal Trans.</td><td>No. of misfeeds that occurred at the paper separator section of the copier</td><td>Sorter</td><td>No. of misfeeds that occurred at the finishing option</td></tr>
<tr><td>Exit Section</td><td>No. of misfeeds that occurred at the exit section of the copier</td><td>ADF Feed</td><td>No. of misfeeds that occurred at the document take-up section of the ADF</td></tr>
</table>
</td></tr>
</table>