9. Accessory Test

- This function is used to make an operation check and adjustments to the ADF and Sorter or Staple Sorter.

Tech. Rep. Mode ▶ Accessory Test

<table>
<tr><th>Touch Panel Display</th><th>Setting (The default is Highlighted .)</th></tr>
<tr><td>ADF Check</td><td>Enables the operation check and adjustments to be performed for the document feeder.</td></tr>
<tr><td>Paper Passage & Input Check</td><td>Makes a paper passage test in each operating mode of the ADF and checks the sensors along the paper path for operation.
<table>
<tr><td>Step Feed</td><td>2in1</td><td>2-Sided</td></tr>
<tr><td>Normal</td><td>SADF</td><td></td></tr>
</table>
<table>
<tr><td>Empty Sensor
ADF Entrance Sensor
Register Sensor
Exit Sensor
Auto Feeder Empty Sensor</td><td>Width Sensor A
Width Sensor B
Width Sensor C
Exit Drawer Sensor
Orig. Guide Home Sensor</td></tr>
</table>
Note: “1” – paper present; “0” – paper not present
<Procedure>
1. Select the operating mode to be checked and touch “Next.”
2. Load the required number of originals into the Document Feed Tray and press the Start key.</td></tr>
<tr><td>Output Check</td><td>Checks each of the motors and solenoids for operation.
<table>
<tr><td>M1</td><td>M2</td><td>M3</td><td>M4</td><td>M5</td></tr>
<tr><td>SL1</td><td>SL2</td><td>SL3</td><td>SL4</td><td>CL</td></tr>
</table>
<Procedure>
• Select the part to be checked and press the Start key.</td></tr>
<tr><td>Doc. Stop Position Set</td><td>Adjusts the document stop position in different operating modes of the ADF.
<table>
<tr><td>1-Sided
2-Sided
2 in 1</td><td>2in1 Space in between origs.
Auto Feeder
Regist Loop</td></tr>
</table>
<table>
<tr><td>Setting</td><td>43 ..... 50 ..... 58</td></tr>
<tr><td>Stop Position</td><td>–7mm ..... 0mm ..... +8mm</td></tr>
</table>
Note: A greater setting value (+ direction) moves away from the Original Width Scale. (In “2in1 Space between origs.,” it is for greater distance between the documents.)
<Procedure>
1. Select the operating mode to be checked and load the required number of originals into the Document Feed Tray.
2. Press the Start key. When the original is taken up and then stopped, raise the ADF and adjust the stop position using the ◀ or ▶ key; then, feed the original once again for a recheck.</td></tr>
</table>