Touch Panel Display	Setting
Sorter Check	Enables the following operation checks to be performed for the Sorter.
Transport Motor	Pressing the Start key energizes the Transport Motor to turn the various Transport Rollers. Note: The 10-Bin Sorter is not operated.
Bin Movement	Pressing the Start key energizes the Bin Moving Motor to move the bins up and down.
Stapling	Pressing the Start key runs a stapling sequence if paper is loaded in the 1st Bin. If no paper is loaded, only a paper clamp motion occurs.
Paper Aligning	Pressing the Start key causes a paper aligning motion to occur for the width of the paper currently selected for use.
Stack move	Pressing the Start key begins a sequence in which paper is stacked in order starting with the paper loaded in the 1st Bin.
	When "Next" is touched after any of the Sorter Check functions has been selected, the "Input Check" screen appears. When that particular check operation is then run with this screen on the Touch Panel, either 1 or 0 is shown after each sensor according to its state.

Paper Aligning Bar Home	Stapler Home
Bin Empty	Bin Home Position
Paper Clamp Position	Staple unit FD move
Paper Clamp Home	Staple Unit CD Constant Position
Staple Paper Detect	Gate Unit constant Position
	Sort path constant Position