6-3. Factory Setting Function Tree



1. Function

Factory Setting ▶ Function

Touch Panel Display	Operation
F2 Drum/Trans	Checks the PC Drum Charge Corona and Image Transfer Corona for output. Note: For factory adjustment only.
F4 HV Separator	Checks the Paper Separator Corona for output. Note: For factory adjustment only.
F6 Edit Ref. Adj	Pressing the Start key turns ON and OFF the Image Erase Lamp to make a checkered pattern on the paper for checking the lamp for correct operation and adjusting its position.