4) C004A: Original Glass Cooling Fan Motor M5's Failure to Turn T-63
C004b: Original Glass Cooling Fan Motor M5 Turning at Abnormal Timing
C004C: Ventilation Fan Motor M3's Failure to Turn
C004d: Ventilation Fan Motor M3 Turning at Abnormal Timing
5) C0070: Main Hopper Toner Replenishing Motor M8's Failure to Turn T-65
C0071: Main Hopper Toner Replenishing Motor M8 Turning at Abnormal Timing
C0072: Sub Hopper Toner Replenishing Motor M9's Failure to Turn
6) C0200 Corona Malfunctions T-67
7) C03##: Master Board/Harness Malfunctions T-68
8) C0400: Exposure Lamp LA1's Failure to Turn ON T-69
C0410: Exposure Lamp LA1 Turning ON at Abnormal Timing
9) C0500: Warming-up Failure T-71
C0510: Abnormally Low Fusing Temperature
C0520: Abnormally High Fusing Temperature
10) C0600: Scanner Motor M2 Malfunction T-73
C06FX: Signal Failure
11) C0610: Lens Motor M6 Malfunction T-75
C0620: Mirror Motor M7 malfunction
12) C0910: 2nd Drawer Upward Motion Failure T-77
C0914: 2nd Drawer Paper Lift-Up Motor M14's Failure to Turn
C0920: 1st Drawer Upward Motion Failure
C0924: 1st Drawer Paper Lift-Up Motor M13's Failure to Turn
13) C0900: 3rd Drawer Upward Motion Failure T-79
C0904: 3rd Drawer Paper Lift-Up Motor M24's Failure to Turn
C0950: 4th Drawer Upward Motion Failure
C0954: 4th Drawer Paper Lift-Up Motor M25's Failure to Turn
14) C0911: 2nd Drawer Upward Motion Failure (Inch Areas) T-81
C0912: 2nd Drawer Downward Motion Failure
C0913: 2nd Drawer Upward Motion Failure
C0916: 2nd Drawer Ejection Failure
15) C0921: 1st Drawer Upward Motion Failure (Inch Areas) T-83
C0922: 1st Drawer Downward Motion Failure
C0923: 1st Drawer Upward Motion Failure
C0926: 1st Drawer Ejection Failure
16) C0901: 3rd Drawer Upward Motion Failure (Inch Areas) T-85
C0902: 3rd Drawer Downward Motion Failure
C0903: 3rd Drawer Upward Motion Failure
C0906: 3rd Drawer Ejection Failure
17) C0951: 4th Drawer Upward Motion Failure (Inch Areas) T-87