Symbol	Parts/Signal Name	Display Page	IC No.	Port No.	I/O	Operation Characteristics/Panel Display		CN/PJ No.
						H or 1	L or 0	
CNT2	Plug-In Counter/REM	1/8	IC1A	P44	■	Normally	When counting	• PJ28A-9
↑	Plug-In Counter/Set	3/8	IC5A	BPC3	|	Out of position	In position	PJ28A-7
H1	Fusing Heater Lamp	1/8	IC1A	P57	○	OFF	ON	PJ33A-2
H3	Paper Dehumidifying Heater	1/8	IC1A	P45	○	ON	OFF	PJ4A-5
RY1	Main Relay	1/8	IC1A	P46	■	ON	OFF	PJ4A-3
LA1	Exposure Lamp/AVR REM	1/8	IC1A	P61	■	OFF	ON	PJ8A-13
LA2	Main Erase Lamp/ REM	2/8	IC4A	BPA1	■	OFF	ON	PJ12A-3
LA2	Main Erase Lamp/ failure detection	2/8	IC4A	APC7	|	OFF	ON	PJ12A-5
S1	Power Switch	1/8	IC1A	P53	|	OFF	ON	PJ4A-1
S21	Front Door Interlock Switch	1/8	IC1A	P51	|	OFF	ON	PJ4A-4
S22	Right Upper Door Interlock Switch	3/8	IC5A	BPB2	|	OFF	ON	PJ16A-2
S23	Left Upper Door Interlock Switch	3/8	IC5A	BPC6	|	OFF	ON	PJ16A-4
S53	Paper Exit Switch	3/8	IC4A	BPB2	|	Paper present	Paper not present	PJ20A-12
S61	Paper Size Detecting Switch 1	1/8	IC3A	BPA6	|	Size yet to be detected	Size detected	PJ26A-2
S62	Paper Size Detecting Switch 2	1/8	IC3A	BPA7	|	Size yet to be detected	Size detected	PJ26A-4
S63	Paper Size Detecting Switch 3	2/8	IC3A	BPB4	|	Size yet to be detected	Size detected	PJ26A-7
S64	Paper Size Detecting Switch 4	2/8	IC3A	BPB5	|	Size yet to be detected	Size detected	PJ26A-9
S106	Toner Empty Detecting Switch	3/8	IC1A	BPC6	|	Toner still available	Toner empty	PJ11A-8B