Symbol	Parts/Signal Name	Display Page	IC No.	Port No.	I/O	Operation Characteristics/Panel Display		CN/PJ No.
						H or 1	L or 0	
PC19	3rd Drawer Paper Lift-Up Sensor	6/8	IC1A	PG3	I	Not at upper limit	At upper limit	PJ6A-12
PC20	3rd Drawer Paper Empty Sensor	5/8	IC1A	PC0	I	Paper not present	Paper present	PJ6A-2
PC21	3rd Drawer Paper Take-Up Sensor	5/8	IC1A	PE3	I	Paper not present	Paper present	PJ6A-9
PC22	Vertical Transport Sensor 4	5/8	IC1A	PC2	I	Paper not present	Paper present	PJ6A-5
PC31	Large Capacity Toner Collecting Box Set Sensor	4/8	IC2A	PC3	I	Out of position	In position	PJ2A-2
PC34	Shift Gate Position Sensor	5/8	IC1A	PC1	I	Un-blocked	Blocked	PJ4A-1B
PC35	Lower Position Sensor	6/8	IC2A	PB3	I	Not at lower limit	At lower limit	PJ4A-2A
PWB-E	Main Tray Paper Empty Board	5/8	IC1A	PF3	I	Paper not present	Paper present	PJ4A-6A
UN21	Drawer Paper Descent Key	6/8	IC2A	PC2	I	OFF	ON	PJ4A-10A
SL41	3rd Drawer Lock Solenoid	6/8	IC2A	PA1	○	OFF	ON	PJ5A-5