	Code	Description	Sensor Layout
Original Size Detecting Board *	C0FF0	Original Size Detecting Sensor ❺ failure	Metric Areas • ❶: PC116, ❷: PC117, ❸: PC118 (option), ❹: PC115, ❺: PC119 (option) • A to E: Sensor locations  Inch Areas • ❶: PC116 (option), ❷: PC117, ❸: PC118 (option), ❹: PC115, ❺: PC119 (option) 
	C0FF1	Original Size Detecting Sensors ❶and ❺ failure	
	C0FF2	Original Size Detecting Sensors ❷ and ❺ failure	
	C0FF3	Original Size Detecting Sensors ❶,❷, and ❺ failure	
	C0FF4	Original Size Detecting Sensors ❸ and ❺ failure	
	C0FF5	Original Size Detecting Sensors ❶,❸, and ❺ failure	
	C0FF6	Original Size Detecting Sensors ❷,❸, and ❺ failure	
	C0FF7	Original Size Detecting Sensors ❶,❷,❸, and ❺ failure	
	C0FF8	Original Size Detecting Sensors ❹ and ❺ failure	
	C0FF9	Original Size Detecting Sensors ❶,❹, and ❺ failure	
	C0FFA	Original Size Detecting Sensors ❷,❹, and ❺ failure	
	C0FFB	Original Size Detecting Sensors ❶,❷,❹, and ❺ failure	
	C0FFC	Original Size Detecting Sensors ❸,❹, and ❺ failure	
	C0FFD	Original Size Detecting Sensors ❶,❸,❹, and ❺ failure	
	C0FFE	Original Size Detecting Sensors ❷,❸,❹, and ❺ failure	
	C0FFF	Original Size Detecting Sensors ❶,❷,❸,❹, and ❺ failure (Metric Areas)	