◆C0000

Step	Check Item	Result	Action
1	Does M1 turn? Set the data of PWB-A (IC4A) BPA2 to "0."	YES	Change PWB-A.
2	Perform the "Controller Board Check." Is malfunction code "C0327" displayed?	YES	Change PWB-A.
		NO	• Check the drive coupling. • Change M1.

◆C0001

Step	Check Item	Result	Action
1	Does M1 turn when the malfunction is reset?	YES	Change PWB-A.
2	Is malfunction code "C0001" displayed again?	YES	Change PWB-A.