◆C004A

Step	Check Item	Result	Action
1	Does M5 turn? Set the data of PWB-A (IC4A) BPC0 to "0."	YES	Change PWB-A.
		NO	Change M5.

◆C004b

Step	Check Item	Result	Action
1	Does M5 turn when the malfunction is reset?	YES	Change PWB-A.
2	Is malfunction code "C004b" displayed again?	YES	Change PWB-A.

◆C004C

Step	Check Item	Result	Action
1	Does M3 turn? Set the data of PWB-A (IC4A) BPC1 to "0."	YES	Change PWB-A.
		NO	Change M3.

◆C004d

Step	Check Item	Result	Action
1	Does M3 turn when the malfunction is reset?	YES	Change PWB-A.
2	Is malfunction code "C004d" displayed again?	YES	Change PWB-A.